

SAFETYWAY PLANE

INFANT BABY WALKING RING

Owner's Manual



Read the instructions carefully before use and assembly of this Walking Ring.

Keep instructions for further use.

Failure to follow these instructions may affect the safety of the child.


IMPORTANT! KEEP FOR FUTURE REFERENCE.

WARNING! TO BE ASSEMBLED BY AN ADULT.

Recommended Max Weight: 12kg

Recommended Age Group: 6 – 18 months

Intended only for children who can sit unaided, approximately 6 months of age.
Not intended for children who can walk by themselves or weigh more than 12 kgs.



Part List - Check all the parts before assembly.

- Walker Frame includes Folding Leg
- Six wheels + two brake pads
- Upper Tray includes Folding Leg
- Adjustable Padded Seat
- Electronic Playtray with two plastic screws
- Footrest Mat
- Pull Handle
- Rear Bar

INSTALLATION AND OPERATING INSTRUCTIONS

Ensure all installation steps have been followed and are stable and secure.

- Insert wheels and brake pads onto the Walker Frame into the corresponding holes.




- Align the Rear Bar with the holes in the Walker Base and press firmly into place.




- Attach the Footrest Mat to the allocated positions on the Walker Base.

- Attach the Padded Seat to the Upper Tray by inserting the plastic clip and pins into the allocated holes.

- Adjust the strap of the Padded seat, to change the seat height appropriate for your growing baby's needs.



- Insert the Folding legs from the Upper Tray onto the Walker Base and click firmly into place. Adjust height to lowest setting using the height Adjuster button.



- Attach the Pull Handle onto the Upper Tray.
- Insert 2 x “AA” 1.5-volt alkaline type batteries (not included) into the electronic Play Tray. (Pay attention to the positive and negative pole installation).
- Attach the Playtray onto the Upper Tray, by lining up the corresponding holes, using the 2 x plastic screws provided, and screw the Playtray on the underneath of the Upper Tray.



FOLDING INSTRUCTIONS

- The Walker folds flat for easy storage and travel.
- Adjust the Height Adjuster buttons to the lowest position.
- Push the Folder Button on the three legs and fold inwards.
- To unfold, simply pull up the Upper Tray and straighten the Folding legs.
- Secure in position.



- Do not place any load on the walker, otherwise it will affect the stability of the product.
- Before use, remove and dispose of any plastic bags and other packaging (e.g fasteners, fixing ties, etc), and keep them out of reach of children.
- Check that the product and all its components have not been damaged during transportation.
- Check regularly that the product is not broken or damaged. If the product is damaged, keep it out of reach of children.
- The product must only be assembled by an adult. For the correct assembly and use of the product, please refer to the following instructions.

STAIR HAZARD

Avoid serious injury or death. Prevent access to stairs, steps and uneven surfaces, slopes or unstable floors, swimming pools or other sources of water. Only use the walker on flat and stable surfaces to ensure walker does not become unstable.



The walker is a tool for toddlers who cannot walk independently. To protect your child from accidental injury, please always check and maintain the walker.

- Before each use, check that the fasteners are secure, and ensure that all folding and locking devices are locked and intact.
- The seat cushion height should be adjusted properly to prevent the child from falling out or accidental injury.
- When cleaning the seat cushion, avoid rubbing it in water, and gently wipe away any stains with a brush or other cleaning tools.
- Avoid overloading.
- Never leave the child unattended. Always keep the child in view while using the walker.
- Guard all fires, heating, and cooking appliances.
- Remove hot liquids, electrical flexes, and other potential hazards from reach.
- Prevent collisions with glass in doors, windows, and furniture.
- Do not use the walker if any components are broken or missing.
- The walker should be used only for short periods of time (e.g 20 – 30 min)
- The walker is not intended for children weighing more than 12kg.
- When moving the walker, the child should not be placed in it.
- Do not use replacement parts other than those approved by the manufacturer.
- The illustrations used in this manual are to explain the assembly, operation method, and structure of the product. When there is a small difference between the real object and the illustrations, the real object shall prevail.
- To ensure that the child is not harmed by accidents, check and maintain the walker regularly.
- Before each use, check that all components are intact and make sure all lockable positions are secured.
- The product is suitable for the age range 6 – 18 months and maximum weight of 12 kgs.
- Wide stable base for extra stability